



MAGIC LITE LTD.

LT-09S-RF

Wireless touching LED Remote 3 Channel Controller for RGB tapelight

1. Technical Parameters (remote control):


- 1) Power supply: AAA battery 3pcs
- 2) Covers material : ABS
- 3) Fabrication Processing: multicolour printing & UV varnish

2. Technical Parameters (controller)

- 1) Working voltage: DC 24V
- 2) Output control: 3 circuits (R/G/B)
- 3) Control current: 6A/ circuit
- 4) Connection method: common anode
- 5) Dimensions: L85 * W64 * H24
- 6) Receiving range: 20 metre

3. Function of Keys

- 1) Keys 1: on / off
- 2) Key 2: light changing modes (15 modes)
- 3) Key 3: colour light / white lighting switching mode
- 4) Key 4: Turn up (brightness / speed)
- 5) Key 5: turn down (brightness / speed)



4. How to use

- 1) Press Key 1 turn on/ off in any state
- 2) Press Key 2 to activate light changing mode, keep pressing for different programs. There are 15 programs in total
- 3) Press key 3 once to active white light mode; you can change brightness by pressing Key 4 or Key Press Key 3 twice to activate colour ring, changing brightness by pressing Key 4 / Key 5 or changing light colour by touching the colour ring
- 4) Resume function. The previous setting will be resumed while power on again.
- 5) To match the remote control to the receiver (you do not need to do this when first out of the box). Press Key 4 once when first switches on within 3 seconds. The light will blink 3 times to indicate that the remote control is matches.
- 6) **Clearing Code:** Press Key 4 x 5 times when first switched on, again, the light will blink 6 times if clearing is successful.

Feature chart for Key 2

1	Auto colour changing	8 grades of brightness to adjust by pressing Key 4 or Key 5
2	Three colours jumps to change	8 grade of speed to adjust by pressing Key 4 or Key 5
3	Seven colours jumps to change	
4	Three colours jump to gradual change	
5	Seven colours jumps to gradual change	
6	Red colour jumps to change	
7	Blue colour jumps to change	8 grade of brightness to adjust by pressing Key 4 or Key 5
8	Purple colour jumps to change	
9	Green colour jumps to change	
10	Yellow colour jumps to change	
11	Cyan colour jumps to change	
12	White colour jumps to change	8 grade of speed to adjust by pressing Key 4 or Key 5
13	Red / blue light twinkles alternately	
14	Green / blue light twinkles alternately	
15	Red / green light twinkles alternately	

5. Caution:

Please don't touch or press the colour ring while loading the batteries to protect the sensitiveness. Please use the remote controller 3 seconds after the batteries are loaded. Please reload the batteries when you find the colour ring is not sensitive.

6. Connection Chart:

