




Digital Timer

Daylight Saving Time (DST)

Press and hold the "CLOCK" button for 3 seconds to advance to the current time 1 hour , "+1h" icon will appear on the display. Press and hold the "CLOCK" button for 3 seconds again to decrease 1 hour and the "+1h" icon will disappear. See Figure 8.



Power Back-up Feature

In the event of a power failure, the timer will retain its settings for an estimated 3 months assuming the power backup is fully charged.

Specifications

120VAC 60Hz
 120VAC 60Hz 15A 1800W General Purpose
 120VAC 60Hz 600W Tungsten
 120VAC 60Hz 1/2HP

Warning

-Use indoors only.
 -Avoid high humidity, high temperature and high magnetic field.

- Keep device out of the reach of children.
- Do not plug this timer into another timer switch.
- Do not connect the device which may exceed the performance limits of the timer.
- Do not insert needles or any other metal objects into mains outlet.
- Do not touch the device with wet hands.
- Do not open the timer.Repairs must be performed by authorized service personnel only.

Limited One Year Warranty

Dewenwils warrants this product to be free from defects in material and workmanship for a period of one year from the date of purchase.Warranty void if damage is due to misuse or improper installation. Please contact us if you have any questions.



Conforms to UL Std. 60730-1, 60730-2-7 and 498A
 Certified to CAN/CSA Std.E60730-1
 Certified to CAN/CSA Std. IEC E60730-2-7 and C22.2 NO.42

Version QM: 1.0
 Stand: 12.08.2016